


# WIRELESS CHIME 232




This package includes (Style of push button and chime may vary from illustration):

- Wireless chime
- Wireless push button w/battery
- Mounting hardware pack

You'll need to buy 2 "C" alkaline batteries for the chime. In typical use alkaline batteries will last up to one year.



- 1. Install alkaline type A23 12 volt push button battery.** Remove back of case by pushing in tab on bottom with a small screwdriver. Make sure battery is oriented properly.
- 2. Open chime case.** Press in catch on bottom of chime and lift the case open.
- 3. Install 2 alkaline "C" batteries.** Make sure batteries are oriented properly.
- 4. Test Range.** Temporarily position chime and push button where you want them mounted. Press push button to verify chime and push button work properly. If chime does not sound, see Troubleshooting.
- 5. Mount push button and chime.**



Use either screws or double sided tape to mount push button.  
To mount with scrws, remove back of case by pushing in tab on bottom with a small screwdriver. Attach back of case to door jamb or wall. Snap front of push button on.  
When attaching push button using double sided tape, make sure the surface of the door jamb or wall is clear.  
Position button with label "Install This End Down".  
Case Style: Chime can be mounted by using 1 screw with keyhole.  
Snap battery access door firmly in place before mounting.

## Code and Tune Settings - Code Settings

Note: **Most installations will not require you to change any jumpers on your chime and push button.**

The push button and chime communicate by using a code that can be changed by removing and/or adding jumpers on both the push button and chime. The code is factory set; however, there are 128 selectable codes that allow you to expand your system and prevent outside interference. Other wireless products may cause interference and the system may not function properly. Follow the instructions below for setting a new code.


1. Open the cases and locate the jumpers on both the push button and chime.
2. The push button and chime both have eight different jumper locations. The jumper positions 1 thru 7 are used for setting the code.
3. To change the code, add and/or remove jumpers as needed. **It is recommended to only change one jumper at a time and then check to see if system is functioning properly.** Note: Jumpers in positions 1 thru 7 must be exactly the same for both the push button and chime for this system to function.

## Tune Setting

Your wireless chime has two different selectable tunes: **Ding** (One note), **Ding-Dong** (two note). The factory setting is for the Ding-Dong tune. This tune can be changed by following the instructions below:

- **Ding** (one note tune)  
Push button: Add a jumper to location 8
- **Ding-Dong** (two note tune)  
Push button: Remove jumper from location 8  
Chime: Remove jumper from location 8

Note: All models have both front and back door tune capabilities. We recommend the back door use the **Ding** tune and the front door use the **Ding Dong** tune.



## Troubleshooting

### Chime doesn't sound:

- Make sure push button and chime codes are the same
- Check orientation of push button battery
- Check charge of push button and chime batteries, replace if necessary.

### Batteries seem OK, but the chime doesn't work when installed:

- Don't mount chime or push button on metal or near metal studs. This reduces the transmitter range. Use 1/4" to 1/2" (6 to 13 mm) wood shims to move chime or push button off metal surface.
- Concrete floors may reduce range. Move chime away from floor.
- Try locating chime closer to push button.

The range of the wireless chime can vary with location, temperature and battery condition.

## Regulatory Information

This device complies with Part 15 of the FCC Rules and RSS-20 of Industry Canada. Operation is subject to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The user is cautioned that changes or modifications not expressly approved by the party responsible for regulatory compliance could void the user's authority to operate equipment

FCC, IC RECOGNIZED

**ONE YEAR LIMITED WARRANTY**

TRINE ACCESS TECHNOLOGY reserves the right to discontinue and to change specifications at any time without notice incurring any obligation to incorporate new features in previously sold products.

1440 Ferris Place • Bronx • NY • 10462

Tel: 718-829-2332 • Fax: 718-829-6405

web-site: [www.trineonline.com](http://www.trineonline.com)

E-mail: [customerservice@trineonline.com](mailto:customerservice@trineonline.com)

**TRINE**™  
ACCESS TECHNOLOGY

REV53002