

# SDC Security Door Controls

801 Avenida Acaso, Camarillo, Ca. 93041 • (805) 494-0622 • Fax: (805) 494-8861  
www.sdcsecurity.com • E-mail: service@sdsecurity.com


## INSTALLATION INSTRUCTIONS E75 STANDALONE ELECTRONIC LOCKSET




**UL US LISTED**  
Electrically Operated Single Point Locks  
& Latches, 3hr 'A' Label Fire Doors

- Keypad Programmable
- 3,000 Users, 32 Temporary Users
- 4 to 6 digit PIN Codes
- 3 Passage Mode Option
- 32 Access Groups, Schedules
- 32 Holidays
- 4 Authority Levels
- Keypad Tamper Lockout
- Mechanical Key Override
- Battery Powered (4AA)
- Blue Backlit Cast Metal Keys
- Weather & Vandal Resistant
- Retrofit existing Lock Door Prep
- Motorized SDC Cylindrical Lockset
- Heavy Duty ANSI Grade 1
- Vandal resistant Lever Handles


Place E75 Template  
on inside of door to  
mark hole locations.




After marking hole  
locations, drill as  
follows;



After drilling  
holes in door,  
use a 1/4"  
Butterfly bit, to  
drill the wire  
raceway where  
shown.




**1** Pass a small pull wire through the raceway hole. This pull wire will be used to bring wires from the lock, to the keypad wiring area.




**2** Install the Lockset. (Refer to lockset instructions)

**3** Attach the pull wire to the wires from the lock. Pull the lock wires through the raceway as you insert the cylindrical lock.



**4** Install the Keypad and Battery pack to the door



**5** Attach wires from the lockset to the keypad using the chart below.

Function	Keypad	Lockset
Motor +	RED/WHT	RED
Output -	WHT/BLK	WHT

**6** Apply power by plugging in the keypad to the battery pack. The left LED will flash rapidly as shown below followed by 3 beeps.




### Specifications

<b>Power</b>	4AA Batteries (Alkaline only) or External 12VDC Power @ 30mA
<b>Inputs</b>	1 Request-To-Exit 1 Door Position Switch
<b>Output</b>	SPDT Contacts 1A @ 30VDC Relay
<b>Temperature</b>	-20° F to +130° F (-30° C to +54° C)
<b>Humidity</b>	5% to 95% non-condensing
<b>Latch Bolt</b>	9/16"
<b>Backset</b>	2-3/4"
<b>Strike</b>	4-7/8" ANSI A115.2
<b>Door Thickness</b>	1-3/4" to 2-1/8"

### Additional Wire Connections

12VDC External Power In	=	RED(+) / BLK(-) (22AWG)
Request-To-Exit	=	BLU(N/O) / BLK(COM)
Door Position Switch	=	GRY / BLK(COM)
Auxiliary Relay	=	ORG (N/C) WHT(COM) YEL(N/O)
System Reset	=	BRN / BRN



E75 TEMPLATE LAYOUT  
HOLLOW METAL DOOR  
161 DOOR PREP  
2-3/4" BACKSET

# Quick Start

## Programming Instructions

### E75 EntryCheck™




### Test the Lock Operation

To test lock operation before initialization, enter **\*741**. This temporary code will unlock the E75 for testing purposes. Once a lock initialization has been performed, this code is no longer active until a hardware reset is performed which will erase all the users and return the E75 back into the uninitialized factory default condition.

### Lock Initialization

When the lock is first installed or after a factory reset has been performed, the E75 must be initialized with a 4-digit lock ID before you will be allowed to enter programming mode.

#### To Initialize Lock:



Press **#9\* 123456# 0001#**   

The above example enters a Lock ID of 0001. If multiple locks are used it is recommended that each lock have its own *Unique* Lock ID (0002, 0003, etc.). This is required when using the E7 Management Software.

### User Programming

NOTE: You must first enter programming mode to perform any other function. 20 seconds of inactivity will automatically exit you from programming mode and return you to operational mode.

#### Enter Programming Mode:

Press **#9# 01# 123456#**    

User 01 with default PIN Code 123456 is the administrator and has full programming rights.

#### Add a User PIN Code (4-6 digits): 01# User No.# PIN Code # Pin Code # Group No.#

Example: Press **01#**  **04#**  **5050#**  **5050#**  **06#**  

You have just added User #04 with a PIN of 5050 to unlock the door.

User 4 has been assigned to group 06 (24/7 access).

#### Add a Single Card: 06# User No.# Present Card


Example: Press **06#**  **04#**  **Present Card**  

You have just added a card to User #4.

User 4 has also be assigned to group 06 (24/7 access).

**Prox Units  
Only**

#### Add a Sequential Batch of Cards: 08# Starting User No.# No. of Cards# Present 1<sup>st</sup> Sequential Card

Example: Press **08#**  **05#**  **10#**  **Present Card**  

You have just added (10) proximity card for User #'s 05 to 14.

All users has also be assigned to group 06 (24/7 access).

#### Exit Programming Mode: \*\*#

Press **\*\*#**    

**Test the lock by pressing 5050#, or present a valid prox card to the reader (prox units only).**

## Additional E75 Programming

Refer to the E75 Programming Guide for a complete list of lock programming functions.

### Change a User PIN Code: 03# User No.# New PIN Code # New Pin Code #

Example 1: Press 03#   01#   123123#   123123#    



You have just changed the Administrator's Pin Code to 123123

**NOTE:** The Administrator's PIN code must be 6 digits in length. All other PIN codes may be 4-6 digits in length

Example 2: Press 03#   04#   1220#   1220#    





You have just changed User #04's Pin code to 1220

### Delete a User: 02# User No.#





Example: Press 02#   04#    

You have just Deleted User #04





### Set Entry Mode : 05# Mode #

Example 1: Press 05#   1#  

Unlock the door either by entering a (PIN + #) or presenting card.

Example 2: Press 05#   2#  

Unlock the door by presenting a valid card.

Example 3: Press 05#   3#  

Unlock the door by presenting card plus the associated user code (PIN + #).

<b>Mode =</b>	1 PIN or Card (default)
	2 Card Only
	3 Card AND Pin







### Set Unlock Timer: 21# Seconds#

Example: Press 21#   03 #    

**Seconds** = 03-20

Unlock timer is set for 03 seconds. (default)

### Beep on Key Press : 62# Status #

Example 1: Press 62#   1#    

**Status** = 0 Disabled

The E75 will beep each time you press a key.

1 Enabled (default)

### Set the Date: 30# MMDDYY#

Example: Press 30#   011513 #    

The date is set for January 15 th 2013

**MM** = 2 digit Month

**DD** = 2 digit Day

**YY** = 2 digit Year

### Set the Time: 31# HH MM#

Example: Press 31#   1320 #    

The time is now set to 1:20 PM.

**HH** = Hours (24hr format)

**MM** = Minutes (24hr format)

### Clear all Programming : 99# 000000 #

Example 1: Press 99#   000000 #    

All user codes are erased and settings are set to factory defaults. The Administrator Pin Code and Lock ID are not cleared.

## Resetting the E75 to Factory Settings

**Warning!!** This procedure will preform a hardware reset and will erase all the users and custom settings returning the E75 back into the uninitialized factory default condition.

- 1) Remove power (Unplug the battery pack)
- 2) Short and hold the 2 Brown Reset wires together
- 3) Apply power. (Plug in the battery pack)



The left LED will light RED for a few seconds, followed by a flashing RED/GRN. When initialization is complete, you will hear 3 beeps.

- 4) Disconnect and insulate the Brown Reset wires.
- 5) Return to Page 4 of these instructions to initialize the lock.

## User Chart

Master Code:	
PIN Length	_____ Digits

[illegible]

**Group Codes:**

Group 01 **Administrator:**  
Full Programming Rights (User 01)

Group 02 **Managers:** May perform programming functions 1-39.

Groups 03-05 **Supervisors:** May perform programming functions 01,02,04,06,07,&08.

Groups 06-32 **User:**  
*No programming rights.* Access granted upon proper  
PIN and group access.

**Notes:**

Groups must have an assigned schedule before they will become active (except Groups 01 & 06).

Group 06 always has 24/7 access.