


## Wiring Diagram For Laundromat kit without key switch

Please use 18 gauge wire

Note: This diagram assumes contact configuration for motion and trigger configuration for timer are default.



## Wiring Diagram For Laundromat kit with key switch

**Please use 18 gauge wire**

Note: This diagram assumes contact configuration for motion and trigger configuration for timer are default.

